



## **HEATER FEMALE**

5 AMP or Less use 1 Pin from (L1) or 1 Pin from (L2)




5 AMP or More use Both Pins from (L1) and (L2) **FEMALE** 



- 1. Phase 1
- 2. Earth
- 3. Phase 2
- 4. RTD B
- 5. RTD A
- 6. Empty
- 7. CAN GND
- 8. CAN NEG
- 9. CAN POS

**MALE** 



- 1. Phase 1
- 2. Earth
- 3. Phase 2
- 4. Empty
- 5. Empty
- 6. Empty
- 7. CAN GND
- 8. CAN NEG
- 9. CAN POS

Dual Phase Controller (VL-22-011-TGD-SC-R1-P1)